


Solar DC-DC Buck-Boost Controller









M2430ND

User Manual



*We may modify these specifications without prior notice.

1. Warnings and Tools Icon Chart

| Icons | Name | Description |
|---|----------------------|---|
|  | High Voltage | High voltage device. Installation should be performed by an electrician. |
|  | High Temperature | This device will produce heat. Mount device away from other items. |
|  | Environmental Hazard | Electronic Equipment. Do not put in landfill. |
|  | Wire Cutter | A wire cutter is needed for cutting and stripping prior wires to connect. |
|  | Multi-meter | A multi-meter is needed for testing equipment and verifying polarity of cables. |
|  | Anti-static Glove | Anti-static gloves are recommended to prevent controller damage caused by static electricity. |
|  | Electrical Tape | Electrical tape is recommended to safely insulate spliced or bare wires. |
|  | Screwdriver | A common size screwdriver is needed to attach wires to the controller. |

2. Safety Tips

- It is very important to review this manual thoroughly before attempting installation.
- Beware of any nearby electrical equipment that may interfere with installing this device. And please don't plug in any AC source to this DC-DC product, or it may cause a fire or burn to the device.
- Solar panels may generate high voltages and currents, and please make sure your solar panels would be completely covered from sunlight during installation. It is recommended that the installation is performed by qualified electricians.
- Contact of wiring to this device may generate sparks, so please put on proper insulation wear while installing this device.
- To avoid damage to the battery or controller, use proper fuses in wiring. Please contact us if you need help with fuse sizing.
- Always keep children away from this device.
- Be certain to use the correct gauge of wire, see below for a table of recommended wire size for various current loads.

| Solar Input Current | 5A | 10A | 20A | 30A |
|--|-----|-----|-----|-----|
| Wire Cross Section Area (mm ²) | 1.5 | 2.5 | 5 | 8 |
| Wire AWG | 15 | 13 | 10 | 8 |

* We suggest no more than 5A's current for each square millimeter's wire core, e.g., for current of 10A, at least you should use 2mm² wire.

3. Product Features

Thank you for choosing our product. This device is a DC-DC intelligent charger/controller for vehicle or similar systems with dual batteries. Applied in a dual battery system, this charger combines respective advantages of motor (ordinary/smart alternator) power generation and photovoltaic power generation.


In use of vehicles, the main/service battery is prior to being charged by the solar input as the default settings. The auxiliary/starter battery would get into charge automatically, after the starter battery was fully charged. Users can also set the charge priority between main & auxiliary batteries in the controller (through the external remote LCD screen). The auxiliary battery could enforce to charge the main battery by settings in the controller, or through the IGN alternator.

The controllers have features as follows:

These MPPT charge controllers have features as follows:

- The external input can supply power to the battery through BUCK-BOOST. The external power sources, like alternator or power supply, are able to charge both main & auxiliary batteries, through a voltage buck-boost circuit.
- Supports dual battery system charge (BAT 1/main/service battery & BAT 2/auxiliary/starter battery). If only one battery would be put in use, then please connect it in the main/service battery port as default settings.
- The charge system would identify PV or external power input as the charge sources, and distribute them to charge both main & auxiliary batteries automatically.
- Both PV and external power sources could be used for charging the dual battery system, and the user can also enforce the charge priority by setting in the remote display.
- By continuously checking solar panel power output changes, the controllers employ multiple MPPT charge algorithms in combination to boost charging efficiency in different weather and temperature conditions.
- If the remote display was connected in the controller, the user could also operate the charge system in App through mobile phones via Bluetooth.
- Charging modes available for most common deep-cycle battery types in the market, including AGM (sealed lead acid batteries/SLD), GEL, Flooded, and Lithium. Auto recognition of 12V/24V battery system voltage.
- Supports recording of system running data for up to 300 days, compatible with monitoring App through iOS and Android.
- Industrial grade design with full ranges of electronic protections on PV and battery in the controller. (optional accessory, not in the standard package list).


4. Device Diagram




| # | Description | # | Description |
|---|--|----|--|
| 1 | LED Indicator (PV,BAT 1,BAT 2,EXT,IGN) | 10 | BVS Input Voltage |
| 2 | Function Key | 11 | External BAT 1Temperature Sensor |
| 3 | PV Positive Terminal | 12 | External BAT 2Temperature Sensor |
| 4 | Battery 1 Positive Terminal | 13 | RS485 Communication Port |
| 5 | Battery 2 Positive Terminal | 14 | Mouting Holes |
| 6 | EXT Input Positive Terminal | 15 | Junction Box Cover Mounting Screw Hole |
| 7 | Public Negative Port | 16 | Junction Box Cover |
| 8 | IGN Single Input | 17 | Shell Ground Connection Point |
| 9 | CAN Communication Port | | |

5. Mounting Instruction

5.1 Wire preparation.




5.2 Remove the mounting cover plate.




5.3 Connect the main wire.

The negative pole of the main wire is the common negative pole, so it can be installed in a random order.



5.4 Connect the communication or the secondary line.




5.5 After connecting the wires, cover the mounting cover plate and tighten the screws.


5.6 Fixed.

5.6.1 Placement.

This device adopts vertical heat dissipation, so it needs to be placed horizontally when it is fixed, so that the hot air can disperse smoothly.



5.6.2 Fixed with self-tapping screws or auxiliary fixing devices.




6. Wire Connection Sequences

* The MPPT charging at PV terminal is buck charging, so the voltage at PV terminal must be greater than the voltage at battery terminal.

* The EXT terminal is Buck-Boost charging, so the input voltage only needs to be within the maximum voltage range 150V.

6.1 Single-battery PV charging system.


The single-battery system supports any connection of the main battery or the secondary battery. The example in the figure below only shows the connection of the battery terminal. Please refer to the following scenarios for the battery connection.



6.2 The Alternator directly connected to the starter battery.


6.2.1 Smart Alternator.

The alternator will lead out the IGN signal line after starting. When the signal line is detected, the machine will detect the voltage of the starter battery. If the voltage is greater than the set voltage, the starter battery will start to charge the living battery.




6.2.2 Regular Alternator.

The alternator will directly charge the starter battery after it is started. When the machine detects the voltage of the starter battery, if it is greater than the set voltage, the starter battery will start to charge the living battery.




6.3 The alternator is connected to the external input port of the controller. (this application is similar to the adapter or power supply directly connected to the external input port)(DC input only)




7. Working Process Introduction


7.1 System operating battery identification.




7.2 The system determines whether the activation is required.




7.3 Switching logic between battery 1 and battery 2 during abnormal operation. (battery with load during operation) (take 12V system as an example)



7.4 Switching logic between battery 1 and battery 2 during normal operation. (battery without load) (take 12V system as an example)




7.5 Buck-Boost charging. (take 12V system as an example)




7.6 MPPT Charging.


MPPT is the abbreviation of Maximum Power Point tracking. Since the photovoltaic curve has the following characteristics, it is hoped that the following Work Point can be tracked when the photovoltaic energy is used for charging.



7.6.1 Lead-acid 3-phases charging.





7.6.2 LI Battery Charging.




7.7 Photovoltaic Characteristics.


7.7.1 PV from dark to normal light. (low light on the left, light enhancement on the right)



7.7.2 The change of light intensity to photovoltaic curve. (weak light on the left and strong light on the right)



7.7.3 The effect of temperature on light. (the higher the temperature, the lower the open circuit voltage, but the overall power is almost the same)



8. LED Flash Rhythm Chart



| LED Name | LED Display | Signal Indication |
|----------|--------------|--|
| PV | Off | Solar Input Not Charging ① * PV LED is generally off during nighttime |
| | Steady On | Charging Mode |
| | Slow Flash | Error |
| B1 | Single Flash | Charging |
| | Slow Fast | Error |
| | Steady On | Connect Normal |
| B2 | Single Flash | Charging |
| | Slow Fast | Error |
| | Steady On | Connect Normal |

| | | |
|-----|-----------|--|
| EXT | Off | External Input Not Charging |
| | Steady On | External Input Detected & DC-DC Charging |
| IGN | Off | Regular Alternator Not Connected |
| | Steady On | Regular Alternator Charging |

① Check the Fault light for possible system errors.

9. Key Function Chart

| Function Key | Input | Input Function |
|--------------|------------|----------------|
| | Long Press | System Reset |

10. LCD Display Interface Overview

Please check the LCD manual for more details.

The LCD screen is used to display the controller data and set controller parameters. Through the connection of the RJ11 crystal head and the controller, the RJ11 crystal head integrates with a 5V power supply and the RS485 communication cable.

LCD Display Interface:

The LCD screen has Welcome, Menu, Main, Set menu, controller battery settings, controller settings, display settings, controller status, historical data (His) and controller information (DCV) interfaces.


Public display area:

There are public display areas on the top of all interfaces except the setting interface and historical interface, which mainly display system status, Bluetooth communication status and controller temperature.

Function Keys:

The display screen has four buttons from the left: set, up, down, and back. The key states include short press, long press and combined press. Long press means that the key is pressed for more than 1.5 seconds. The combined key means that the set is pressed first and then other keys are pressed.


10.1 Welcome interface(startup interface).



Interface description:

- When powered on, the screen first enters the welcome interface, and then exits after 2 seconds to enter the main interface.


10.2 Main interface.



Interface description:

- The 4 icons from left to right are PV, Battery 1, Battery 2 and EXT.
- The data corresponding to the PV icon are PV voltage and PV charging state.
- The data corresponding to the battery 1 icon are battery 1 voltage, battery 1 charging current and controller temperature.
- The data corresponding to the battery 2 icon are battery 2 voltage, battery 2 charging current and external temperature.
- The data corresponding to EXT icon are EXT voltage and EXT charging state.


10.3 Menu interface.



Interface description:

- The menu interface provides access to other interfaces, from left to right are main interface, setting menu interface, status interface, historical data interface and controller information(DCV) interface.

Setting menu



Interface description:

- The setting menu interface provides access to all setting interfaces, from left to right: controller battery setting, controller setting and screen display setting.

10.4 Setting interface.


Battery settings interface

| Para1 | Curr | Type | Vol | Over Vol |
|-------|------|------|--------|----------|
| Bat1 | 30 | USE | AUTO | 16.0 |
| Bat2 | 30 | FLD | [AUTO] | [16.0] |

Interface description:

· There are 3 interfaces in the setting interface: battery setting, controller setting and display setting. All setting interfaces display relevant parameters in the form of tables. You can move the selected table by pressing the button and modify the corresponding parameters. For specific operation methods, please refer to "LCD Screen Manual".

10.6 Historical data interface.




The historical data is generated once a day, and the daily data includes:

- The charging power of PV to BAT1 and BAT 2.
- The charging power of EXT to BAT 1 and BAT 2.
- The maximum and minimum voltage of BAT1.
- The maximum and minimum voltage of BAT 2.
- PV maximum charging current.

A maximum of 500 days of historical data can be recorded, and the specific operation method can be found in the "LCD Screen Manual".

11. Product Dimension



10.5 Status interface.

| Sta | | 25°C/77°F | |
|-------------|-------------------------|---------------------------|-------|
| PV: | 55.3V | 17W | FLOAT |
| EXT MOT: | 0.0V | 0W | IDLE |
| BAT1: | 13.8V | 1.20A | 0.0A |
| BAT2: | 0.0V | 0.0A | 0.0A |
| TEMP: | Controller 25°C/77°F | Surroundings --°C/--°F | |

Interface description:

- The status interface displays the real-time data of PV, EXT, BAT and TEMP.
- PV: PV voltage, PV charging power, PV charging status.
- EXT MOT: EXT voltage, EXT charging power, EXT charging status.
- BAT: BAT voltage, charging current from PV to BAT, charging current from EXT to BAT.
- TEMP: Controller temperature, ambient temperature.

12. Controller Specification

The variable “n” is adopted as a multiplying factor when calculating parameter voltages, the rule for “n” is listed as: if battery system voltage is 12V, n=1; 24V, n=2.

For example, the equalize charge voltage for a 12V FLD (Flooded) battery bank is $14.8V \times 1 = 14.8V$. The equalizing charge voltage for a 24V FLD (Flooded) battery bank is $14.8V \times 2 = 29.6V$.

| Parameter | Value |
|------------------------|--|
| Charging Mode | MPPT |
| No-load Loss | 25mA |
| System Wiring Grounded | Negative Grounded |
| Operating Temperature | -25°C ~ 45°C |
| Storage Temperature | -35°C ~ 65°C |
| Operating Altitude | <3000m |
| IP Protection | IP45 |
| Charging Efficiency | >98% |
| Communication Port | RS485/CAN(Optional) |
| Charging Derating | Step derating and recovery at 70°C |
| Connectors | Bare wire terminals (V6) |
| Wire Gauge | 10mm ² (8AWG) |
| LED Instructions | PV,BAT1,BAT2,EXT,IGN |
| Operating Mode | External Display |
| Bluetooth | The built-in Bluetooth module of the display screen operated by APP |
| Protection | PV Over-Voltage, PV Reverse Protection, Battery Over Voltage, Battery Over-Charge, Battery Reverse Protection, External input Over-Voltage, EXT Reverse Protection, Controller Over-Heating, High Ambient Temperature. |

| Battery 1 | |
|-------------------------------------|--|
| Battery | Service Battery |
| Battery System Voltage | 12/24V AUTO |
| Battery Voltage Range | 8V-32V |
| Battery Type | GEL/SEL/FLD/USE/LI |
| Max Current | 30A |
| BVS | Yes |
| Battery 2 | |
| Battery | Starter Battery |
| Battery System Voltage | 12/24V AUTO |
| Battery Voltage Range | 8V-32V |
| Battery Type | GEL/SEL/FLD/USE/LI |
| Max Current | 30A |
| BVS | No |
| PV | |
| Charging Mode | Buck MPPT+CC+CV |
| Max Solar Input Power | 450W / 900W |
| Max Solar Input Voltage | 60Voc |
| PV Tracking Efficiency | >99% |
| EXT (External charging equipment) | |
| Charging Mode | DC-DC Buck-Boost Charging |
| Equipment Type | DC Alternator, Adapter, Charger, Power Supply, Battery |
| Max Charging Current | 30A |
| EXT Input Voltage Range | 8V-35V |
| Max EXT Input Power | 450W / 900W |